

Your Bluetooth Beacon

The LiveLife Watch comes with a Bluetooth Beacon to place inside your home. The Beacon has been programmed by us with the exact co-ordinates of your home address you supplied with your order. When you activate the SOS on your LiveLife Watch while at home it will look for the Beacon and those programmed co-ordinates so it can send that exact location in its help text messages via Google Maps.

If you are outdoors, wearing your LiveLife Watch and out of range of Bluetooth it will use GPS, or Wifi to get your location.

Leave your Beacon at home

Your Beacon is meant to be left at home. If you move house please call us on 1877 801 7172 so we can arrange to re-program your beacon. If you holiday in another location purchasing a second beacon could be a sensible option.


Testing the accuracy of your beacon

You can test your beacon by sending a SMS to your LiveLife Watch from a mobile phone. Send the SMS command: **LOC**

If the Watch is on and the Beacon is on the response will be:

Location by Beacon

Plus also your location and time information.



Batteries

We have installed 2 x AAA batteries in your Beacon. These are expected to last at least 12 months. We recommend you change these each time your annual SIM card renewal is due.

To change the batteries:

- Rotate the bottom of the beacon to the open state (clockwise).
- Bottom should fall out on its own. If not give it a bit of a tap. Then replace AAA batteries.

Bluetooth distance

The Bluetooth maximum distance between Beacon and Watch is 100 metres uninterrupted. i.e. With no walls or obstructions in between.



www.livelifearms.com.au

1 877 801 7172